

## WARNING!

Adult assembly required. Inflate using supplied hand held pump and adapter. Take care not to over inflate. Packaging materials are not toys. Remove all packaging including pump and adapter before giving this toy to a child.

Use only under competent adult supervision. Young children in play are unaware of potential dangers and hazards. Adult supervision is essential.

Ensure play area is clear of any obstruction and sharp objects. Remove any sharp objects from children and play area, as these could cause injury to the user or damage the Bouncy Rider.

Recommended age 1 year +. Maximum user weight 50Kg.

Not to be used as a floating aid.

Do not expose to extreme temperatures. It is best to store item inside and away from direct sunlight.

Clean with warm soapy water only.

## Limited Warranty Statement

Your Kaper Kidz Bouncy Rider is warranted to be free from defects in the material and workmanship for a period of 3 Months from the date of purchase. If our product is damaged due to manufacturing fault, please either return it to the original place of purchase or contact us. Prior to returning the item, please obtain a return authority code from [enquiries@elegant.com.au](mailto:enquiries@elegant.com.au)

The limited warranty is void if the unit is physically damaged, used in a manner contrary to intended use, or otherwise abused either intentionally or unintentionally. These include toys that have been physically damaged, punctured or overinflated.

Please be aware that toys have been damaged due to inflation via mechanical air compressor are not covered by the warranty.

Also specifically excluded is the pump and needle, these are considered a free item. If damaged or lost, it will not be covered by the warranty.

## Inflation Guide

Fix the metal adapter into the bottom of the pump.

Insert pump with adapter into valve on the underside of the Bouncy Rider and inflate.

Once fully inflated remove the pump and adapter. Store pump for future use.

Inflation with a compressor may burst the Bouncy Rider and is not recommended.

PVC can be stretched over time, add more air as required.

Over or under inflation can cause injury to the user and damage the Bouncy Rider.

